

Wichtig / Important !

FATAR TP/40GH - Montagehinweise/Assembly Instructions

Im Ruhezustand der Tasten ist die Oberfläche zum rückwärtigen Ende der Tastatur hin geneigt, wie es auch bei akustischen Klavieren und Flügeln der Fall ist. **Es darf auf keinen Fall versucht werden, die Tastatur durch rückwärtiges Anheben so zu montieren, dass die Tastenoberfläche im Ruhezustand waagrecht ist!** In diesem Fall würde der vordere Teil des Tastaturrahmens nicht mehr plan auf der Bodenplatte aufliegen, sodass sich beim Festschrauben der Rahmen stark verzieht. Die Folge wären Funktionsstörungen an der Hammermechanik oder sogar Schäden, die **nicht unter unsere Garantieleistungen fallen.**

*The surface of the keys at rest is sloping towards the rear end of the keybed as well as with acoustical grand pianos. **Never lift the rear end of the keybed frame to achieve a plane surface at rest.** In this case the front part of the frame will no longer lie flat on its supporting surface. Screwing the keybed in this position will warp the metal frame and cause distortions of the hammer action or even damages. **This is not covered by our warranty!***

